



RTS

Home ACCENTS

Assembly Instructions

DIY MILLENNIAL BENCHENDS W/O BACK REST

Read these instructions and general information to properly and safely assemble the DIY Bench Ends.

Jan 18, 2021
Revision 01

5701-00300F-xx-xx

Please contact RTS Companies for any questions or concerns

RTS Companies

1.800.663.2803 (CAN)

1.888.641.3077 (USA)

info@rtscorporationsinc.com

Content s:

2 bench ends

Required (not included):

5 equal lengths of 2x4 lumber (maximum 5')

6 deck screws (3.5" long)

Drill

Method:



1. Tools Needed: Drill, 6 Deck Screws (3.5" L x 6), 5 pieces of lumber (up to 5' long).



2. Lay one of the bench ends on the ground and insert each of the pieces of lumber into the slots. Make sure the wood is flush with the outer side of the bench end.



3. From the under side of the seat, drill 1 screw into each section, through the wood. On the corners, make sure to drill on an angle. Do not overtighten.



4. Place second bench end over pieces of wood. Ensure the wood is flush with the outer side of the bench end.



5. From the under side of the seat, drill 1 screw into each section, through the wood. On the corners, make sure to drill on an angle. Do not overtighten.



6. Grab your favourite beverage and enjoy your view!